




# Android Settings for Dorani Touch Wi-fi Intercom

You can have up to 3 devices connected to the intercom to receive calls while not at home

This document is a guide to SAMSUNG Android devices. Some phone settings may need to be changed in order to get the intercom to call your mobile device

For instructions on the initial set-up, please see the WIFI supplement provided with your intercom or visit [www.dorani.com.au](http://www.dorani.com.au) for a copy


**If more than one device is connected, only the first to answer receives the call**



**Download the 2-easy APP**

**Either scan the QR code or search**


**'2-Easy' in the APP store or google play**



1 : Open the APP, Allow all access requests. Then press the scan button




2 : Press the 'Server' button




3 : Scan the QR code with your phone


**If you are experiencing issues with the intercom calling your phone, try the steps below.**




Select 'Menu'



Select 'Advanced'




Select 'Settings'




Select 'Android app settings'







Select 'Notifications'



Ensure **all** are enabled



Select 'Battery'




Ensure "Allow background activity" is **enabled**







Select 'Settings'



Select 'Device Care'




Select 'Battery'




Select 'App power management'





Select 'Apps that won't be put to sleep'



Add "2-Easy" app to the list

**Your device will now be able to receive calls from the intercom. For further inquiries, please contact your installer or contact Dorani at [support@dorani.com.au](mailto:support@dorani.com.au)**